
10
12
16
18
11
14
111
110
30
90
25
22
20
23
26
24
21
28
27

FIG. 1A


12
12
10
10
16
16
18
18
14
14
30
30
20
20

FIG. 1B



FIG. 1C


12
10
16
18
14
52
54
104
110
111
106
50
76
56
11
29
77
58
74
59
83
72
62
92
III
III
68
60
71
67
64
66
30
90
70
84
85
86
82
28
22
23
24
20

FIG. 2A


DETECT BONUS ACTIVATING EVENT
170
DRIVE DISPLAY
172
DETECT PLAYER INPUT OR WAIT A PREDETERMINED PERIOD OF TIME
174
ACTIVATE AGITATOR
176
SELECT PRIZE BALL TO BE DISPLAYED
178
DRIVE POSITIONING MECHANISM POSITION BALL HOLDER TO DISPLAY SELECTED BALL
180
DRIVE DISPLAY MECHANISM TO DISPLAY SELECTED PRIZE BALL
182
WAIT A PREDETERMINED PERIOD OF TIME
184
DRIVE DISPLAY MECHANISM TO STOP DISPLAYING SELECTED PRIZE BALL
186
DEACTIVATE AGITATOR
188

FIG. 2B



FIG. 2C


58
92
62
62
92
62
92
62
92
62
62
92
92
62
62
59
92
62
92
62
62
92
62
92
62
92
62

FIG. 3


92
62
92
62
92
62
92
62
61
92
62
92
62
92
62
92
62
92
62
92
62
92
62
92
62
92
62

FIG. 4


72
102
62
92
58
100
64
68
67
66

FIG. 5A


62
73
72
75
58
92
71
83
77
66
64
29
30
114
60
112
56

FIG. 5B


92
58
62
66
64
92
58
62
66
64
92
58
62
64
68
66

FIG. 6


158
152
150
92
92
154
154
156
154
92
154
30
164
92
154
92

FIG. 7


204
B I N G O
202
200
RED
YELLOW
BLUE
GREEN
ORANGE
206
208
210
GREEN
B
212
214

FIG. 8


236
230
4
2
6
1
5
8
7
3
9
30
2
92

FIG. 9



FIG. 10



FIG. 11



FIG. 12



FIG. 13



FIG. 14



FIG. 15



FIG. 16



FIG. 17



FIG. 18


628
660
630
600
602
606
614
604
608
612
616
618
622
620
626
610
624
632

FIG. 19


658
660
600
656
608
634
636
640
610
638
645
642
652
648
644
634
646
654
650
632

FIG. 20


661
658
690
600
608
659
674
676
666
664
672
682
610
640
678
688
668
670
680
644
684
662
686
650
654
632

FIG. 21



FIG. 22



FIG. 23



FIG. 24A


920
928
936
934
902
930
912
924
948
926
908
918
944
910
922
906
940
916
904
914
938

FIG. 24B



FIG. 24D



FIG. 24E



FIG. 24C



FIG. 24G



FIG. 24F



FIG. 25


750
758
770
B I N G O
752
756
751
754
760
762
35 08 15 33 05
01 15 06 17 23
12 40 16 38 04
02 03 31 25 11
18 14 34 37 44

FIG. 26



FIG. 27


820
822
PLACE WAGER ON GAMING DEVICE
824
PLAY BASE GAME ON GAMING APPARATUS
826
HAS BONUS-ACTIVATING EVENT OCCURED?
YES
NO
828
NOTIFY PLAYER OF GAME OUTCOME FROM BASE GAME
830
JUMBLE DISPLAY BALLS
832
SELECT A PRIZE BALL RANDOMLY
834
DISPLAY SYMBOL CORRESPONDING TO THE SELECTED PRIZE BALL ON GAME DISPLAY
836
WINNING ARRANGEMENT OF DISPLAYED SYMBOL ON GAME DISPLAY
838
PLAYER ENTITLED TO ANOTHER BONUS GAME?
NO
YES
840
AWARD PRIZE TO PLAYER

FIG. 28



FIG. 29



FIG. 30